



# Ultimaker 2+ Connect Air Manager Product data sheet

Upgrade your peace of mind

The Ultimaker 2+Connect Air Manager <sup>1</sup> gives you more confidence and setup flexibility. Designed to increase user safety, it removes up to 95% of ultrafine particles (UFPs) while top and front enclosures shield users from hot and moving components.

#### Key features

- EPA filter :Removes up to 95% of UFPs  $\checkmark$
- Enhanced safety :Encloses the top and front of the printer
- Easy setup :Printer detects when the Air Manager 1 is connected

### Ultimaker 2+Connect Air Manager specifications

Properties	Filter technology	EPA filter	
	Fan technology	Air extraction by low-noise brushless fan	
	Filter efficiency	Up to 95%	
	Filter replacement	Recommended every 1,500 print hours (approx.1 year)	
	Operating sound	<51 dBA (including printer)	
	Connection (data and power)	UMB connection (included)	
	Compatible materials	Optimized for Ultimaker PLA, ToughPLA, ABS, Nylon, CPE, (Also supports third-party materials)	CPE+, PC, PP,TPU 95A
Physical dimensions	Dimensions (XYZ)	<b>328 x 459 x 257 mm</b> (12.9 x 18.1 x 10.1 in)	
	Dimensions (includingprinter)	342 x 460 x 636 mm (13.5 x 18.1 x 25 in)	
	Shipping box dimensions	<b>491 x 401 x 380 mm</b> (19.3 x 15.7 x 15 in)	
	Net weight	2.65 kg (5.8 lbs)	
Warranty	Warranty period	12 months	Ultimaker
			1.1 March 1.1 Ma

1 Requires Ultimaker 2+Connect 3D

printer. For illustrative purposes, the Air Manager is shown with the printer



v1.00

## Ultimaker